











# Socket Flat Head Size Chart

www.boltdepot.com/tools



Fastener length is measured from where the material surface is assumed to be, to the end of the fastener.

0 . . . . . 1 . . . . . 2 . . . . . 3 . . . . . 4 . . . . . 5 . . . . . 6 inches

Scale Check: After printing, measure ruler above to ensure correct scale