
Metric Socket Cap Sizes


www.boltdepot.com/tools

-_ in


Bolt Depot .com


Fastener length is measured from where the material surface is assumed to be, to the end of the fastener.























Copyright © 2000-2017 Bolt Depot Inc.

IMPORTANT: Make sure to print this chart to Actual Size (no scaling).

After printing, measure the ruler in the margin to ensure correct scale. See **boltdepot.com/tools** for more details.